

ENSURING THE CO2 BULB IS CENTRED IN THE FIRING PIN HOUSING...



PLACE A 20mm SQUARE OF TAPE ONTO THE TOP OF THE BULB



SQUEEZE AND TWIST IT DOWN EVENLY AROUND THE FIRING END ON THE BULB.

THIS SHOULD GREATE A FIRM BUT NOT JAMMED UP FIT AND ENSURE THAT THE PIN MAKES A GOOD SIZED HOLE.